


Ersatzteilliste
Spare parts list
Liste des pièces de rechange



Scrubby

Einscheibenmaschine
Single Disc Machine
Monobrosse





Pos.	Art. Nr.	Bezeichnung	Désignation	Designation
1	715.050	Motorgehäuse rechts	boîte de moteur droit	housing right
2	715.051	Motorgehäuse links	boîte de moteur gauche	housing left
3	715.059	Motor Scrubby	moteur	motor
4				
5				
6	715.054	Schraube für Griff	vis pour manche	screw for handle
7				
8				
9	715.056	ON/OFF Schalter	interrupteur on off	on off switch
10				
11				
12				
13				
14	715.055	ON/OFF Schalter	interrupteur on off	on off switch
15				
16				
17				
18				
19				
20				
21	715.062	Spritzschutz	protection d'eau	splash protection
22				
23				
24				
25				
26	715.057	Padhalter	porte disc	pad holder
27	715.010	Akku Met. Hybrid 9 Volt	accu batterie	accu battery
28	715.030	Nylon Bürste 145mm	brosse standard	brush standard
	715.031	Tynex Bürste 145mm	brosse tynex	brush tynex
29	715.063	Teleskopgriff komplett	poignée télescopique	telescopic handle comp.
30	715.045	Griff Scrubby	poignée	handle
31	715.012	Schnell-Ladegerät für 9V	chargeur	charger
32	715.015	Mains-connector VDE	Mains-connector VDE	Mains-connector VDE
	715.016	Mains-connector SEV	Mains-connector VDE	Mains-connector VDE